




PARTS CALLED OUT BY NUMBER INDICATE RELATIVE POSITION OF COMPONENTS. ADJACENT PARTS AND ASSEMBLIES ARE SHOWN ON THE SAME LETTERED DRAWING AS THE PART CALLED OUT.

ASSEMBLY A			33H	MOTOR	1
1	OUTER COWL	1	H11	REVERSING SWITCH	1
2	INNER COWL	1	H12	SWITCH KNOB	1
3	JOINT BAND	1	34	MOTOR MOUNT ANGLE	4
4	ASSEMBLY CLIP	8	35	MOTOR MOUNT GROMMET	4
5	CLIP RIVET	16	36	MOTOR MOUNT SCREW	4
ASSEMBLY B			37	TUBE CLIP	1
6	BRACKET-PLAIN	2	ASSEMBLY E		
7	BRACKET-WIRING PIVOT	1	38	END GRILLE	1
8	BRACKET-FRICTION PIVOT	1	39	NAME PLATE	1
9	STUD	8	40	SIDE GRILLE	1
10	CROSS PIN	8	ASSEMBLY F		
11	WIRING TUBE	1	41H	END COVER	1
12	PIVOT-WIRING	1	42	COVER SCREW	4
13	PIVOT-FRICTION	1	43	YOKE	1
14	STOP PIN	2	44	YOKE STOP	2
15	EXPANSION PLUG	1	45	YOKE GROMMET	1
16	EXPANSION SCREW	1	ASSEMBLY G1		
17	YOKE CAP-WIRING	1	46	BASE	1
18	YOKE CAP-FRICTION	1	47	BASEPLATE	1
19	CAP COVER-WIRING	1	48	BASEPLATE SCREW	10
20	CAP COVER-FRICTION	1	49H	DECALCOMANIA	1
21	CAP SCREW	4	50	FOOT	4
22	SNAP HOLE PLUG	1	51	FOOT RIVET	4
23	PIVOT RETAINING SCREW	2	52H	MOTOR SWITCH	1
24	LOCKWASHER	2	53H	SPEED CONTROL REACTOR	1
ASSEMBLY C			54	CONTROLLER MOUNT SCREW	2
25H	OUTER DEFLECTOR	1	55H	CORD SET	1
26H	INNER DEFLECTOR	1	56	CORD BUSHING	1
27	MOUNTING SCREW	8	ASSEMBLY G2		
H1	INSULATOR	19	57	CLAMP SPRING	1
H2	INSULATOR CLIP	19	58	SPRING PAD	2
H3	OUTER ELEMENT	1	59	BELL CRANK	2
H4	INNER ELEMENT	1	60	CRANK STUD	2
H5	TERMINAL SCREW	4	61	CLAMP NUT	1
H6	TERMINAL WASHER	8	62	WASHER	2
H7	LOCKNUT	8	63	CLAMP SCREW	1
H8	SPACER	4	64	RETAINING RING	1
H9	EYELET	4	65H	SWITCH ESCUTCHEON	1
H10	HEATER LEAD	3	66	CLAMP ESCUTCHEON	1
ASSEMBLY D			67	ESCUTCHEON SCREW	6
28	HUB	1	68	SWITCH KNOB	1
29	BLADE	4	69	CLAMP KNOB	1
30	BLADE RIVET	16	70	SETSCREW	1
31	BALANCE WEIGHT	—	71	CLAMP KNOB BEARING	1
32	DRIVE GROMMET	1	72	WALL MOUNT SCREW	2
NO.	PART NAME	Q'TY	NO.	PART NAME	Q'TY

PORTABLE AIR CIRCULATOR

ASSEMBLY FULL SIZE H

MASTER ASSEMBLY - PICTORIAL